## Classroom Technical Guide

Dail 88 for IT Support, the IT Client Services Center is located on the 5th floor in room N525

Note: Don't save data on classroom computers, all data on classroom computers will be deleted beyond recovery on every restart or shutdown.

## Your classroom is equipped with the following:

In the equipment rack:

 Classroom Local PC (Mac Mini) and loaded with standard desktop software On the Lecture

- Keyboard/Mouse (for local PC)
- 1 Monitor (for local PC)
- USB Hub (for local PC)
- IP Phone(dail 88 for IT support)
- Laptop connection cables (USB-C,HDMI)
- 1 Microphone with charging station

In the room

- Extron button control panel
- 1 Ceiling-mounted projector and screen
- 1 Ceiling-mounted Array microphone

Use the Extron unit to control the room equipment. The unit is on the wall.



- 1. Find the button panel on the
- 2. wall near to the door
- 3. Press "on" to turn on the system



- 4. The projector will be on
- 5. The screen will lower down
- 6. Front row lights will be off




- 7. Login in Classroom PC with NetID & Password
- 8. Press "PC" on the button panel to display Classroom PC Desktop to projector




- Connect personal Laptop or tablet with appropriate cable
- 10. Press "Laptop" on the button panel



- 11. Find the e-control panel icon on classroom PC dock station
- 12. Click the e-control panel icon to launch the control panel on PC



 Click on "Video" to enable microphone of Zoom application on classroom PC for mixed mode class



14. Press "Off "on button panel to shut down the system



- 15. Put the microphone to the charging station after use,
- 16. the charging station indicator will lit on red



Take your belonging with you and keep the lectern tidy after class